

LOAD CASE DEFINITION KEY

CASE 1 (HYD) WW+HP
CASE 2 (OPE) W+T1+P1
CASE 3 (Alt-SUS) W+P1
CASE 4 (OPE) W+T2+P1
CASE 5 (Alt-SUS) W+P1
CASE 6 (OPE) W+T3+P1
CASE 7 (Alt-SUS) W+P1
CASE 8 (OPE) W+T4+P1
CASE 9 (Alt-SUS) W+P1
CASE 10 (OPE) W+T5+P1
CASE 11 (Alt-SUS) W+P1
CASE 12 (SUS) W+P1
CASE 13 (EXP) L13=L2-L12
CASE 14 (EXP) L14=L4-L12
CASE 15 (EXP) L15=L2-L4
CASE 16 (EXP) L16=L6-L12
CASE 17 (EXP) L17=L2-L6
CASE 18 (EXP) L18=L4-L6
CASE 19 (EXP) L19=L8-L12
CASE 20 (EXP) L20=L2-L8
CASE 21 (EXP) L21=L4-L8
CASE 22 (EXP) L22=L6-L8
CASE 23 (EXP) L23=L10-L12
CASE 24 (EXP) L24=L2-L10
CASE 25 (EXP) L25=L4-L10
CASE 26 (EXP) L26=L6-L10
CASE 27 (EXP) L27=L8-L10